Table of Contents

BS2_GetDataEncryptKey

[+ V2.6.0] Gets data encryption key.

Declaration

```
#include "BS_API.h"

int BS2_GetDataEncryptKey(void* context, uint32_t deviceId, BS2EncryptKey*
keyInfo);
```

> See BS2EncryptKey Structure

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *keyInfo* : Structure address of encryption key information which will be returned

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_SetDataEncryptKey
BS2_RemoveDataEncryptKey