

Table of Contents

[USB Exported Control API](#) > [BS2_GetLogSmallBlobFromDir](#) --- =====

[BS2_GetLogSmallBlobFromDir](#)===== [+ 2.6.4] Retrieves logs filtered by EventMask from the USB exported data.

The difference from [BS2_GetLogBlobFromDir](#) which is using [BS2EventBlob](#) is that the parameter `imageObj` in [BS2EventSmallBlob](#) is changed to pointer for memory efficiency.

Except this, everything is the same. ===== Declaration ===== `cpp` `#include "BS_API.h" int BS2_GetLogSmallBlobFromDir(void* context, const char* szDir, uint16_t eventMask, BS2_EVENT_ID eventId, uint32_t amount, BS2EventSmallBlob logsObj, uint32_t* numLog);` </code>

BS2EventSmallBlob구조체 보기

===== Parameter ===== * [In] `context` : Context * [In] `szDir` : Data storage path * [In] `eventMask` : event mask * [In] `eventId` : Log record ID, retrieves from the first record if it is 0 * [In] `amount` : Maximum log amount, retrieves all after eventId if it is 0 * [Out] `logsObj` : Pointer of storing the log record address * [Out] `numLog` : The number of log records

NOTE

The `logsObj` variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

===== Return Value ===== If successfully done, `BS_SDK_SUCCESS` will be returned. If there is an error, the corresponding error code will be returned. ===== See Also =====

[BS2_AllocateUsbContext](#)
[BS2_ReleaseUsbContext](#)
[BS2_GetUserDatabaseInfoFromDir](#)
[BS2_GetUserListFromDir](#)
[BS2_GetUserInfosFromDir](#)
[BS2_GetUserDatasFromDir](#)
[BS2_GetUserInfosExFromDir](#)
[BS2_GetUserDatasExFromDir](#)
[BS2_GetLogFromDir](#)
[BS2_GetFilteredLogFromDir](#)
[BS2_GetLogBlobFromDir](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getlogsmallblobfromdir&rev=1581989650

Last update: **2020/02/18 10:34**