

Table of Contents

BS2_GetScheduledLockUnlockZoneStatus	1
Declartion	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_GetScheduledLockUnlockZoneStatus](#)

BS2_GetScheduledLockUnlockZoneStatus

Retrieves the status of selected Scheduled Lock/Unlock zones.

Declaration

```
#include "BS_API.h"

int BS2_GetScheduledLockUnlockZoneStatus(void* context, uint32_t deviceId,
uint32_t* zoneIds, uint32_t zoneIdCount, BS2ZoneStatus** zoneStatusObj,
uint32_t* numZoneStatus);
```

[See BS2ZoneStatus Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *zoneIds* : List of Scheduled Lock/Unlock zone IDs
- [In] *zoneIdCount* : Size of Scheduled Lock/Unlock zone ID list
- [Out] *zoneStatusObj* : Zone status list pointer
- [Out] *numZoneStatus* : Number of zone status records

NOTE

The *zoneStatusObj* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetScheduledLockUnlockZone](#)

[BS2_GetAllScheduledLockUnlockZone](#)
[BS2_GetAllScheduledLockUnlockZoneStatus](#)
[BS2_SetScheduledLockUnlockZone](#)
[BS2_SetScheduledLockUnlockZoneAlarm](#)
[BS2_RemoveScheduledLockUnlockZone](#)
[BS2_RemoveAllScheduledLockUnlockZone](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getscheduledlockunlockzonestatus

Last update: **2016/07/12 10:16**