

Table of Contents

BS2_GetUserInfosFaceExFromDirWithKey	1
Declaration	1
Parameters	1
Return Value	1
See Also	1

[USB Exported Control API](#) > [BS2_GetUserInfosFaceExFromDirWithKey](#)

BS2_GetUserInfosFaceExFromDirWithKey

[+2.8.2] Gets the log after a given log record ID from the data extracted by USB by a maximum amount.

Supports USB files exported from FaceStation F2 devices.

Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosFaceExFromDirWithKey(void* context, const char* szDir,
char* uids, uint32_t uidCount, BS2UserFaceExBlob* userBlob, const
BS2EncryptKey* key);
```

[View the structure of the BS2UserFaceExBlob](#)

Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *uids* : List of user identifiers to be imported
- [In] *uidCount* : Number of user identifiers
- [Out] *userBlob* : Pointer to store user information
- [In] *key* : Encryption key and the key value specified by [BS2_SetDataEncryptKey](#)

Return Value

Returns BS_SDK_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

See Also

[BS2_GetUserDatasFaceExFromDirWithKey](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getuserinfosfaceexfromdirwithkey

Last update: **2022/04/21 09:53**