

Table of Contents

BS2_GetUserSmallInfosExFromDir	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[USB Exported Control API](#) > [BS2_GetUserSmallInfosExFromDir](#)

BS2_GetUserSmallInfosExFromDir

[+ 2.6.3] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)

The only difference between [BS2_GetUserInfosExFromDir](#) which is using structure [BS2UserBlobEx](#) is that the 5th parameter `BS2UserPhoto` of [BS2UserSmallBlobEx](#) is using pointer for efficient memory use.

Declaration

```
#include "BS_API.h"

int BS2_GetUserSmallInfosExFromDir(void* context, const char* szDir, char*
uids, uint32_t uidCount, BS2UserSmallBlobEx* userBlob);
```

[See BS2UserSmallBlobEx Structure](#)

Parameter

- [In] *context* : Context
- [In] *szDir* : Storage path in device
- [In] *uids* : User ID list trying to get
- [In] *uidCount* : Number of user ID
- [Out] *userBlob* : Pointer to store the user information

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.

See Also

[BS2_GetUserSmallInfosFromDir](#)
[BS2_GetUserSmallDatasFromDir](#)
[BS2_GetUserSmallInfosExFromDir](#)
[BS2_GetUserSmallDatasExFromDir](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getusersmallinfosexfromdir

Last update: **2019/06/18 16:29**