

Table of Contents

BS2_SetAccessLevel	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Access Control API](#) > [BS2_SetAccessLevel](#)

BS2_SetAccessLevel

Configures an access level.

Declaration

```
#include "BS_API.h"

int BS2_SetAccessLevel(void* context, uint32_t deviceId, BS2AccessLevel*
accessLevels, uint32_t accessLevelCount);
```

[See BS2AccessLevel Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *accessLevels* : List of access levels to be stored
- [In] *accessLevelCount* : Number of access levels

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetAccessLevel](#)
[BS2_GetAllAccessLevel](#)
[BS2_RemoveAccessLevel](#)
[BS2_RemoveAllAccessLevel](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setaccesslevel

Last update: **2016/07/12 09:01**