

# Table of Contents

<b>BS2_SetAutoConnection</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1
See Also .....	1

[Communication API](#) > [BS2\\_SetAutoConnection](#)

---

## BS2\_SetAutoConnection

Set auto connection.

If it is set, it automatically calls the connected callback function specified in [BS2\\_SetDeviceEventListener](#) after the socket connection from the device is accepted.

### Declaration

```
#include "BS_API.h"

int BS2_SetAutoConnection(void* context, int enable);
```

### Parameter

- [In] *context* : Context
- [In] *enable* : Weather auto connection is enabled

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_IsAutoConnection](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2\\_setautoconnection](http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_setautoconnection)

Last update: **2018/11/02 12:17**