

# Table of Contents

|                                 |   |
|---------------------------------|---|
| <b>BS2_SetSlaveDevice</b> ..... | 1 |
| Declaration .....               | 1 |
| Parameter .....                 | 1 |
| Return Value .....              | 1 |
| See Also .....                  | 1 |

[Slave Control API](#) > [BS2\\_SetSlaveDevice](#)

---

## BS2\_SetSlaveDevice

Add/Modify/Delete a slave device from the master device.

### Declaration

```
#include "BS_API.h"

int BS2_SetSlaveDevice(void* context, uint32_t deviceId,
BS2Rs485SlaveDevice* slaveDevices, uint32_t slaveDeviceCount);
```

[See BS2Rs485SlaveDevice Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *slaveDevices* : List of slave devices
- [In] *slaveDeviceCount* : Number of slave devices

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_GetSlaveDevice](#)

From:  
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:  
[https://kb.supremainc.com/kbtest/doku.php?id=en:bs2\\_setslavedevice](https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_setslavedevice)

Last update: **2016/07/12 09:32**