

Table of Contents

BS2_SetTimedAntiPassbackZoneAlarm	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_SetTimedAntiPassbackZoneAlarm](#)

BS2_SetTimedAntiPassbackZoneAlarm

Configures the alarm status of the timed Anti Passback zone.

Declaration

```
#include "BS_API.h"

int BS2_SetTimedAntiPassbackZoneAlarm(void* context, uint32_t deviceId,
uint8_t alarmed, uint32_t* zoneIds, uint32_t zoneIdCount);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *alarmed* : Whether the alarm has been triggered or not
- [In] *zoneIds* : List of timed Anti Passback zone IDs
- [In] *zoneIdCount* : Number of timed Anti Passback zone IDs

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetTimedAntiPassbackZone](#)
[BS2_GetAllTimedAntiPassbackZone](#)
[BS2_GetTimedAntiPassbackZoneStatus](#)
[BS2_GetAllTimedAntiPassbackZoneStatus](#)
[BS2_SetTimedAntiPassbackZone](#)
[BS2_RemoveTimedAntiPassbackZone](#)
[BS2_RemoveAllTimedAntiPassbackZone](#)
[BS2_ClearTimedAntiPassbackZoneStatus](#)
[BS2_ClearAllTimedAntiPassbackZoneStatus](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_settimedantipassbackzonealarm

Last update: **2016/02/17 14:39**