

Table of Contents

| | |
|------------------------------|---|
| BS2_WriteQRCode | 1 |
| Declaration | 1 |
| Parameter | 1 |
| Return Value | 1 |

 **Fix Me!** This page is not fully translated, yet. Please help completing the translation.
(remove this paragraph once the translation is finished)

[Smartcard API](#) > [BS2_WriteQRCode](#)

BS2_WriteQRCode

[+ 2.8] Write the character strings to use QR code in the structure BS2CSN Card for X-Station 2
Available QR Code Data of X-Station 2 QR is up to 32 characters with the printable ASCII code from 32 (space) to 126(~) in ASCII table.

Declaration

```
#include "BS_API.h"

int BS2_WriteQRCode(const char* qrText, BS2CSNCard* card);
```

[See BS2CSNCard](#)

Parameter

- [In] *qrText* : Character string setting as QR Code
- [Out] *card* : CSN Card Structure pointer with applied QR Code

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is not supported character string, the error code BS_SDK_ERROR_INVALID_PARAM will be returned.

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_writeqrcode&rev=1622975350

Last update: **2021/06/06 19:29**