

BS2_RemoveAllIntrusionAlarmZone 1

..... 1

..... 1

..... 1

..... 1

..... 1

BS2_RemoveAllIntrusionAlarmZone


BioStation 2 (1.5.0 only)
BioStatioin A2 (1.4.0 only)
BioEntry P2 (1.0.0 only)

```
#include "BS_API.h"  
  
int BS2_RemoveAllIntrusionAlarmZone(void* context, uint32_t deviceId);
```

- [In] *context* : Context
- [In] *deviceId* :

BS_SDK_SUCCESS , 가

- [BS2_GetIntrusionAlarmZone](#)
- [BS2_GetIntrusionAlarmZoneStatus](#)
- [BS2_GetAllIntrusionAlarmZoneStatus](#)
- [BS2_SetIntrusionAlarmZone](#)
- [BS2_SetIntrusionAlarmZoneAlarm](#)
- [BS2_RemoveIntrusionAlarmZone](#)
- [BS2_SetIntrusionAlarmZoneArm](#)



From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_removeallintrusionalarmzone

Last update: **2018/03/22 10:50**