

**Control API** ..... 1

**executeOutputAction** ..... 1

        ..... 1

        ..... 1

**executeLedAction** ..... 1

        ..... 1

        ..... 1

**setEthernetConfig** ..... 2

        ..... 2

        ..... 2

**openRS232** ..... 2

        ..... 2

        ..... 2

**closeRS232** ..... 3

        ..... 3

**readRS232** ..... 3

        ..... 3

        ..... 3

**writeRS232** ..... 3

        ..... 3

        ..... 4

# Control API

## executeOutputAction

(Relay)

```
int executeOutputAction(Channel channel, Relay relay)
```

- channel: (0~1)
- relay:

Channel  
Relay

SUCCESS 가

## executeLedAction

LED

```
int executeLedAction(LedColor color)
```

- color: LED

LedColor

SUCCESS 가

# setEthernetConfig

```
int setEthernetConfig(boolean enableDHCP, String ip, String subnet, String gateway, String dnsServer)
```

- enableDHCP: DHCP
- ip: IP
- subnet:
- gateway:
- dnsServer: DNS

SUCCESS

가

API

, onActivityResult

가

# openRS232

RS232

```
int openRS232(int baudrate)
```

- baudrate: RS232

SUCCESS

가

## closeRS232

RS232 .

```
int closeRS232()
```

SUCCESS

가 .

## readRS232

RS232 .

```
int readRS232(RS232Data data)
```

- data: RS232

RS232Data

SUCCESS

가 .

## writeRS232

RS232 .

```
int writeRS232(RS232Data data)
```

- data: RS232

RS232Data

SUCCESS

가

From:

<http://kb.supremainc.com/svpsdk/> - **SVP Android SDK**

Permanent link:

[http://kb.supremainc.com/svpsdk/doku.php?id=ko:control\\_api&rev=1568942886](http://kb.supremainc.com/svpsdk/doku.php?id=ko:control_api&rev=1568942886)

Last update: **2019/09/20 10:28**